
\$750 Air Tool Specifications

Safety Procedures

Air Line Requirements





Air Line Requirements

Air Line Pressure: 100 PSI Minimum, 150 PSI Maximum

Consumption: 3-5 CFM

Line Size: 1/4" I.D. Minimum

Connection: 1/4" N.P.T.

Filter/Lubricator: Located in Air Supply in back of Air

Tool.

Lubricant: SAE 10 Wt. Non-Detergent Motor Oil



Safety Procedures

- 1. Familiarize yourself with operating procedures before operating the S750 Air Tool.
- Do not operate tool without cover in place.
- 3. Use only recommended Band-It preformed clamps.
- 4. Do not exceed recommended pressure settings. Excess pressure may cause sudden clamp failure during application or result in an unsafe clamp.
- 5. Always keep fingers clear of clamp during application.
- 6. Disconnect air supply before servicing air tool.
- 7. Tool must be firmly mounted (see Installation Instructions, Page 4).
- 8. Safety glasses or goggles should be worn when applying clamps.
- 9. Always keep tool in good operating condition.